

DESCALING CARTRIDGE

Quick and efficient descaling of the Kärcher SC 3 EasyFix steam cleaner. All you need to do is insert the cartridge, and you're done.



Order no. **2.863-018.0**

Technical data

EAN code		4054278026213
Weight	kg	0.1
Weight incl. packaging	kg	0.1
Dimensions (L × W × H)	mm	56 × 56 × 163



Automatic indicator lamp for cartridge replacement

- The indicator lights up once the service life of the descaling cartridge has expired.

Simple and quick cartridge replacement

- Simply replace the cartridge and press the reset button on the device.

COMPATIBLE MACHINES

- SC 3 Upright EasyFix
- SC 3 Upright EasyFix
- SC 2 Upright EasyFix
- SC 2 Upright EasyFix *GB
- SC 3 EasyFix
- SC 3 EasyFix
- SC 3 EasyFix
- SC 3 Easyfix